



Illus	Description	Part No.	Illus	Description	Part No
	KITS		101	E clutch steel	5 212 12 22
	Overhaul	211 02 01	102	E clutch end plate	212 12 20
	Gasket & rubber	211 03 01	103	E clutch diaphragm spring	134 X 67 X 12T 211 24 05
	Gasket	211 04 01			
	Shaft seling rings	211 06 01	110	F clutch friction	143 x 1.6 x 30T 6 211 11 03
			111	F clutch steel	6 211 12 06
	GASKETS		112	F clutch spring plate	208 12 02
1	Pan	211 25 01	113	F clutch end plate	211 12 07
2	Stator support	211 25 02	114	F clutch diaphragm spring	208 24 06
3	V/B intermediate plate	211 25 03		FILTERS	
				Pickup	211 27 01
	RUBBER COMPONENTS			Valve body thimble screen	208 27 02
10	Pump	213 16 01		BUSHES & BEARINGS	
11	Sleeve	211 16 01	115	Converter needle bush	211 21 01
12	B clutch inner	211 16 02	116	Support bush	211 21 02
13	B clutch outer	180 16 11	117	F clutch needle bush	178 21 02
14	A clutch inner	211 16 03	118	Output ball bearing	208 21 04
15	A clutch outer	213 16 03		THRUST WASHERS	
16	A clutch oil dam	213 16 03	130	Pump	208 22 01
17	C clutch inner	211 16 04	131	Intermediate shaft	211 22 01
18	C clutch outer	180 16 12	132	C clutch plate carrier	211 22 02
19	Sun gear shaft	2 211 16 05			
20	D clutch inner	211 16 06	133	Input shaft needle	211 23 01
21	D clutch outer	211 16 07			
22	E clutch inner	211 16 08	134	Kit of sel thrusts	211 10 01
23	E clutch outer	180 16 11	134	Input shaft front sel	3.0 211 22 03A
24	Support bush	211 16 09	134	Input shaft front sel	2.8 211 22 03B
25	Support bush	211 16 10	134	Input shaft front sel	2.6 211 22 03C
26	Ring gear	211 16 11	134	Input shaft front sel	2.4 211 22 03D
27	F clutch to case	208 16 14			
28	F clutch moulded piston	211 45 01	134	Input shaft front sel	2.2 211 22 03E
29	Extension housing	208 16 19	134	Input shaft front sel	2.0 211 22 03F
30	V/B wire harness	2 208 16 18	134	Input shaft front sel	1.8 211 22 03G
31	Filter	208 16 15	134	Input shaft front sel	1.6 211 22 03H
32	Pressure regulator	1 211 16 13	134	Input shaft front sel	1.4 211 22 03J
33	Pressure regulator	4 211 16 14			
34	Input shaft	211 16 10	135	D cylinder	211 22 04
			136	E clutch disc carrier needle set	211 23 02
			137	Sun gear needle thrust	211 23 03
	METAL CLAD SEALS				
40	Converter	137 15 01	138	Set of sel thrust plates	208 10 03
41	Extension	208 15 01	138	Selective thrust plate	3.2 211 22 05A
42	Selector shaft	2 211 15 01	138	Selective thrust plate	3.0 211 22 05B
			138	Selective thrust plate	2.8 211 22 05C
			138	Selective thrust plate	2.6 211 22 05D
	SHAFT SEALING RINGS				
50	Stator support	2 208 26 02	138	Selective thrust plate	2.4 211 22 05E
51	Input shaft	2 213 26 03	138	Selective thrust plate	2.2 211 22 05F
52	Sun gear shaft	2 211 26 01	138	Selective thrust plate	2.0 211 22 05G
53	Input shaft	1 211 26 02	138	Selective thrust plate	1.8 211 22 05H
54	Pump	1 211 26 03			
			138	Selective thrust plate	1.6 211 22 05J
	CLUTCH PLATES		138	Selective thrust plate	1.4 211 22 05K
60	B clutch friction	178 x 1.6 x 30T 6 211 11 01	138	Selective thrust plate	1.2 211 22 05L
61	B clutch steel	6 212 12 22	138	Selective thrust plate	1.0 211 22 05M
62	B clutch spring plate	1 211 12 01	139	Input shaft rear needle set	211 23 04
63	End plate	212 12 20			
64	B clutch diaphragm spring	122 X 86 X 16T 211 24 01		CIRCLIPS	
70	A clutch friction	128 x 1.6 x 40T 6 211 11 02	150	Pump	208 32 02
71	A clutch steel	6 211 12 02	151	B clutch diaphragm spring	211 32 01
72	A clutch end plate	211 12 03			
73	A clutch spring plate	211 12 04	152	B clutch selective	4.6 211 32 02A
74	A clutch diaphragm spring	91 X 37 X 10T 211 24 02	152	B clutch selective	4.4 211 32 02B
80	C clutch friction	128 x 1.6 x 40T 4 211 11 02	152	B clutch selective	4.2 211 32 02C
81	C clutch steel	4 211 12 02	152	B clutch selective	4.0 211 32 02D
82	C clutch spring plate	211 12 04	152	B clutch selective	3.8 211 32 02E
83	C clutch end plate	211 12 05			
84	C clutch diaphragm spring	96 X 60 X 12T 211 24 03	152	B clutch selective	3.6 211 32 02F
90	D clutch friction	178 x 1.6 x 30T 4 211 11 01	152	B clutch selective	3.4 211 32 02G
91	D clutch steel	4 212 12 22	152	B clutch selective	3.2 211 32 02H
92	D clutch spring plate	211 12 01	152	B clutch selective	3.0 211 32 02J
93	D clutch end plate	212 12 20			
94	D clutch diaphragm spring	168 X 140 X 20T 211 24 04	152	B clutch selective	2.8 211 32 02K
100	E clutch friction	178 x 1.6 x 30T 5 211 11 01	152	B clutch selective	2.6 211 32 02L
			152	B clutch selective	2.4 211 32 02M
			152	B clutch selective	2.2 211 32 02N
			153	C clutch disc carrier	211 32 03



Iss 10/08/98

Please quote the full transmission code when ordering parts

1997 on - 5 speed rear wheel drive transaxle. Jaguar & BMW

ZF 5HP24**1058 000**

Illus	Description	Part No.	Illus	Description	Part No
154	A clutch dam	211 32 04	214	Clutch disc carrier	211 29 10
155	A clutch selective 3.6	211 32 05A	214	Clutch disc carrier	211 29 11
155	A clutch selective 3.4	211 32 05B	215	Ring gear	211 29 12
155	A clutch selective 3.2	211 32 05C	216	Planet carrier	211 66 01
155	A clutch selective 3.0	211 32 05D	217	Ring gear	211 29 13
155	A clutch selective 2.8	211 32 05E	218	Sun gear	211 65 02
155	A clutch selective 2.6	211 32 05F	219	Planet carrier	211 66 02
155	A clutch selective 2.4	211 32 05G	220	Sun gear	211 65 03
155	A clutch selective 2.2	211 32 05H	221	Ring gear	211 29 14
155	A clutch selective 2.0	211 32 05J	225	Planet carrier	211 66 03
155	A clutch selective 1.8	211 32 05K	226	Freewheel assembly	211 44 01
156	C clutch selective 3.4	211 32 06A	227	Fixing washer	208 29 18
156	C clutch selective 3.2	211 32 06B	228	F clutch split ring	208 29 19
156	C clutch selective 3.0	211 32 06C	230	F clutch cylinder	211 29 15
156	C clutch selective 2.8	211 32 06D	231	F clutch screws	208 37 01
156	C clutch selective 2.6	211 32 06E	235	Park lock wheel	211 29 16
156	C clutch selective 2.4	211 32 06F	236	Slotted output nut	208 29 21
156	C clutch selective 2.2	211 32 06G	237	Output flange	211 57 01
157	D clutch housing	211 32 07	ELECTRICAL		
158	D & E clutch selective 4.6	211 32 08A		Switch	211 35 01
158	D & E clutch selective 4.4	211 32 08B		V/B wire harness	211 35 03
158	D & E clutch selective 4.2	211 32 08C	3	Solenoid	213 35 11
158	D & E clutch selective 4.0	211 32 08D	4	Pressure regulator	213 35 10
158	D & E clutch selective 3.8	211 32 08E	1	Pressure regulator	213 35 09
158	D & E clutch selective 3.6	211 32 08F		V/B Ind transmitter	178 35 01
158	D & E clutch selective 3.4	211 32 08G	CONVERTER		
158	D & E clutch selective 3.2	211 32 08H		Jaguar code 014, 024	211 30 07
158	D & E clutch selective 3.0	211 32 08J		Jaguar code 009, 013	211 30 06
158	D & E clutch selective 2.8	211 32 08K		Jaguar code 015	211 30 08
158	D & E clutch selective 2.6	211 32 08L		BMW code 018	211 30 09
158	D & E clutch selective 2.4	211 32 08M		BMW code 004, 010, 017	211 30 05
158	D & E clutch selective 2.2	211 32 08N		BMW code 003, 005, 016	211 30 04
159	D clutch diaphragm spring	211 32 09	TOOLS		
160	Ring gear	211 32 10		Wallchart	211 33 10
161	Ring gear	211 32 11			
162	Ring gear	211 32 11			
163	Freewheel	208 32 23			
164	Freewheel fixing washer	208 32 24			
165	F clutch selective 3.8	208 32 05			
165	F clutch selective 3.4	208 32 07			
165	F clutch selective 3	208 32 09			
165	F clutch selective 2.6	208 32 11			
166	Output ball bearing	208 32 06			
167	F clutch bearing	208 32 25			
HARD PARTS					
180	Pump assembly	211 38 01			
181	Pump wear plate	211 38 03			
182	Stator assembly	211 39 01			
182a	Stator housing only	211 39 03			
183	B clutch cylinder	211 29 01			
184	B clutch piston	211 45 02			
185	B clutch fixing washer	211 29 02			
186	Intermediate shaft	211 29 03			
187	Clutch disc carrier	211 29 04			
188	Clutch disc carrier	211 29 05			
192	Input shaft	211 64 01			
193	A clutch piston	211 45 03			
194	A clutch oil dam	211 29 06			
199	C clutch piston	211 45 04			
200	C clutch cylinder	211 29 07			
201	C clutch split ring	208 29 18			
202	Sun gear shaft	211 65 01			
205	D clutch piston	211 45 05			
206	D & E clutch assemblies	211 29 08			
210	E clutch piston	211 45 06			
211	E clutch split ring	211 29 09			

